PARABOND PARQUET 240



CHARACTERISTICS

- 1-component parquet adhesive
- Ready-to-use
- Excellent stance (adhesive lines remain stable)
- Permanent elasticity
- Very easy to apply
- · High end strength
- Suitable for use with underfloor heating
- Better acoustic comfort
- Solvent, water, isocyanate and phthalate free
- · EC1 Plus label: very low VOC emissions
- · Low odour

APPLICATIONS

- · For both absorbent and non-absorbent surfaces.
- · Bonding of ABS.
- Suitable for all sizes of multilayer parquet flooring (or composite parquet) that complies with the EN 13489 standard, chipboard, OSB and plywood.
- · Suitable for anhydrite screed floors.
- Suitable for bonding parquet on floors with underfloor heating.

TECHNICAL CHARACTERISTICS	
Type of product	Hybrid polymer
Density (g/ml)	1.71
Number of components	1
Shear strength (N/mm²)	2
Temperature resistance	-40°C - +90°C
Curing system	Curing by air humidity
Sandable after	48 h
Walkable after	24 h
Working time at 23 degrees C and 50% R.H.	30 minutes
Temperature product when applying	+15°C - +35°C
Shore A hardness: ISO 868	50
Dry matter content	±100%
Shelf life of unopened product	15 months
Storage conditions	Store in a dry, cool place at +5°C to +25°C. Keep out of direct sunlight.

bucket 15kg - 33 pieces/pallet Beige box 22,5kg - 36 pieces/pallet Beige box 2 x 7,5kgd - 40 pieces/pallet Beige

This technical data sheet replaces all previous editions. The data on this sheet have been compiled according to the last laboratory report. Technical characteristics can be changed or adapted. We are not responsible for any incomplete information. Before use, one needs to ensure that the product is suitable for his application. Therefore, tests are necessary. Our general conditions apply



Last Update: 29-04-2024

METHOD OF USE

Preparation

- Use in well-ventilated rooms. Good ventilation is important during application and curing of the product.
- It is recommended to carry out tests on every surface before use.
- The user needs to make sure that the product is suitable for the application. Consult our technical service if necessary.
- Remove irregularities such as old adhesive residues mechanically
- Preferably roughen/sand smooth surfaces to increase the contact surface.
- Uneven floors should be levelled first using a levelling layer like DL Egaline of DL Maxi Egaline.
- Any cracks or fissures must be repaired with synthetic mortar that can be obtained by mixing Hydroblocker 2K with quartz sand.
- Cementitious screeds with high residual moisture can be treated with Primer PU Turbo (max. 4% residual moisture) or Hydroblocker 2K (max. 5% residual moisture).
- Existing ceramic, granite, marble or similar floors should be properly degreased and then mechanically scratched. In case of rising damp, they must be treated with a three-component primer Hydroblocker 3K.
- In any case, do not apply a moisture barrier to screeds with underfloor heating, any residual moisture present will have to be removed by switching on the heating system, prior to installation.
- If the screed is in extremely poor condition, it must be removed and replaced.
- Measure the moisture content of the substrate using a carbide meter and compare to the value of the flooring manufacturer. In accordance with TV 272 of BBRI: max 2.5% for cement screed and 0.5% for anhydrite; with underfloor heating, 1.8% and 0.3%.
- Preferably let the parquet acclimatize for a few days in the original packaging in the relevant room.
- Underfloor heating must have dilated at least 48 hours before installation.
- The surface should be permanently dry, clean and free from dust, paint, loose parts..., and must retain its pressure and form. Check whether surface complies with the applicable norms and technical regulations.
- Surfaces that are not sturdy or compact enough must be reinforced with Primer WB, Primer PU Turbo or Hydroblocker 2K.

Primers

It is necessary to apply the Primer WB or Primer PU Turbo before use on highly absorbent surfaces.

Application

- The product should be applied directly to the substrate with a coarsely serrated adhesive trowel. The adhesive must be spread evenly over the entire surface.
- Please note the working time of the adhesive. Don't apply too much adhesive in one stroke.
- Slide the parquet into the wet adhesive on the substrate and tap with a rubber hammer. The material can at this stage still be adjusted, just push it down well.
- The gap between the wall and the parguet must be at least 10-15 mm.
- If necessary, the parquet could be slightly loaded to ensure perfect spread of the adhesive. Many wood species should be tamped down from above. Parquet without tongue and groove should be rolled down using a cylinder roller.

Cleaning

- Any adhesive that may protrude along the edges can be removed using a stopping knife. Adhesive residue that has not yet dried, can be removed using Parasilico Cleaner, Multi-Purpose Super Cleaner or Cleaning Wipes.
- Tools, surfaces and uncured residues can be removed with Parasilico Cleaner, Multi-Purpose Super Cleaner or Cleaning Wipes. Remainder of silicone can be removed with Silicone Remover after curing

This technical data sheet replaces all previous editions. The data on this sheet have been compiled according to the last laboratory report. Technical characteristics can be changed or adapted. We are not responsible for any incomplete information. Before use, one needs to ensure that the product is suitable for his application. Therefore, tests are necessary. Our general conditions apply



info@dl-chem.com - www.dl-chem.com

Last Update: 29-04-2024

· After curing remove mechanically.

SAFETY

Consult the safety information on the packaging and the safety data sheet for more information.


POINTS OF ATTENTION

- Not suitable for permanent submersion.
- Not suitable for use on butiminous surfaces.
- Not suitable for use on PE, PP, PA, PTFE (Teflon).
- Avoid contact with plasticizer-containing materials such as bitumen, neoprene, EPDM, butyl... as these can lead to loss of adhesion or discoloration.
- Not suitable for application outside.
- As there is an extended range of parquet floors on the market, you have to make sure that the product is suitable for the intended application.

TECHNICAL APPROVALS

- GEV Emicode EC1plus label: very low VOC emissions
- French VOC emission class A+





This technical data sheet replaces all previous editions. The data on this sheet have been compiled according to the last laboratory report. Technical characteristics can be changed or adapted. We are not responsible for any incomplete information. Before use, one needs to ensure that the product is suitable for his application. Therefore, tests are necessary. Our general conditions apply



Last Update: 29-04-2024