

**CHARACTERISTICS**

- The tape comprises an airtight foil-fleece combination
- The self-adhesive affixing strip enables the foil tape to be simply applied in such a way that it is completely concealed
- Can be plastered and painted over
- Stretchable

**APPLICATIONS**

- Suitable for renovation and new building work.
- Paraband W Interior for the airtight sealing of the internal window connecting joint.
- The affixing strip applies a high level of adhesive force to all kinds of window frame.

**TECHNICAL CHARACTERISTICS**

Type of product	PES-PE-PES
Thickness: DIN 53855 (mm)	0.48
Weather / UV resistance	3 months
Sd value	ca. 39 m (DIN 4108 T.3)
Water resistance	> 3000 mm (DIN EN 20811)
Application temperature	+5°C - +40°C
Temperature resistance	-40°C - +80°C
Weight: DIN 53854 (g/m <sup>2</sup> )	138
Tear strength: DIN 53 857 longitudinal (N/5cm)	304
Tear strength: DIN 53 857 transverse (N/5cm)	50
Tear elongation: DIN 53 857 longitudinal (%)	23
Tear elongation: DIN 53 857 transverse (%)	134
Density water vapour diffusion: EN 53 122 (g/m <sup>2</sup> x d)	0.96
Airtightness: EN 1026	An ≤ 0,1
Fire class: DIN4102-1	B2
Shelf life of unopened product	12 months
Storage conditions	Store in a dry, cool place at +5°C to +25°C. Keep out of direct sunlight.

**PACKING AND COLOURS**

Pink
100 mm : 4 x roll 30M/box - 192 pieces/pallet
150 mm : 2 x roll 30M/box - 96 pieces/pallet
200 mm : 2 x roll 30M/box - 96 pieces/pallet
250 mm : roll 30m - 48 pieces/pallet
300 mm : roll 30m - 48 pieces/pallet

**METHOD OF USE****Preparation**

This technical data sheet replaces all previous editions. The data on this sheet have been compiled according to the last laboratory report. Technical characteristics can be changed or adapted. We are not responsible for any incomplete information. Before use, one needs to ensure that the product is suitable for his application. Therefore, tests are necessary. Our general conditions apply

- The surface should be permanently dry, clean and free from dust, paint, loose parts.... and must retain its pressure and form. Check whether surface complies with the applicable norms and technical regulations.

## Application

- Unroll Parabond W Interior and cut it so that there is sufficient excess length.
- Pull off the masking paper from the transfer adhesive and adhere the tape to the window frame so that it is concealed.
- Form a loop at each of the corners. Press the adhesive strips of the loops so that it is possible to ensure an airtight connection. Adhere to the 4 sides of the window frame.
- Mount the window frame.
- Fill in the function levels with Parafoam Flexible. We recommend the use of Parabond Construction for adherence to the masonry substrate.
- Do not lay the tape from the window frame to the masonry in a steep slope as the applied plaster will otherwise be too thin and tear.

## Cleaning

- Residue adhesive can be removed with Parasilico Cleaner. The skin can be cleaned with soap and water.

This technical data sheet replaces all previous editions. The data on this sheet have been compiled according to the last laboratory report. Technical characteristics can be changed or adapted. We are not responsible for any incomplete information. Before use, one needs to ensure that the product is suitable for his application. Therefore, tests are necessary. Our general conditions apply