



CHARACTERISTICS

- 1 component adhesion and moisture primer based on polyurethane
- Strengthens powdery and brittle, absorbent subfloors
- Improves the adhesion of parquet adhesive to the subfloor
- Allows to quickly continue working: parquet flooring can already be laid after 1 hour
- Ready to use
- Solvent-free
- Does not contain VOCs
- Not flammable

APPLICATIONS

- Suitable as an adhesion primer on cementitious subfloors (screed) that are powdery and brittle.
- Suitable as an adhesion primer on dry anhydrite subfloors (<0.5% residual moisture).
- Suitable as an adhesion primer for ceramic tiles.
- Suitable as an adhesion primer for underfloor heating, if the subfloor is dry.
- Suitable as a moisture barrier for cementitious subfloors with a residual moisture of up to 4% (measured with carbide meter).
- Suitable as an adhesion primer and moisture barrier for leveling mortar. It is recommended to sand in the primer.
- Can be used as a synthetic repair mortar for small cracks and cracks (≤ 5 mm) in the screed when mixed with fine, dry sand.

TECHNICAL CHARACTERISTICS*	
Aspect	Liquid
Colour	Brown
Curing system	Cures by moisture in air and substrate
Density	1,170 g/cm ³
Viscosity (Brookfield)	220 mPa.s
VOC content	0 g/l
Processing temperature	>+10°C
Consumption as an adhesion primer	$\pm 8 - 12$ m ² /liter (1 layer)
Consumption as a moisture barrier	$\pm 5 - 8$ m ² /liter (2 layers)
Dust dry / walkable	50 - 70 min.
Floor laying	Min. 1 h - max. 72 h (optimal 24 h)
Completely cured	± 24 h
Shelf life, in original closed packing in a dry, cool place free of frost with temperatures above 10°C	12 months

* Measured at 20°C, 60% RH

PACKING

Canister of 10 liters - 50 canisters / pallet

METHOD OF USE

Substrate

- The surface to be treated (absorbent and insensitive to moisture) must be clean and free from any substance that can come loose or tear.
- If the latter is the case, the necessary repairs can be carried out with **synthetic mortar** prepared with **Primer PU Turbo** and dried fine sand (0.3 - 0.5 mm).
- Fine cracks in the substrate (max. 5 mm) can be repaired with synthetic mortar, by mixing **Primer PU Turbo** and dried fine sand (primer/sand ratio 1:6). To improve the adhesion of the mortar on powdery surfaces, a layer of pure **Primer PU**

This technical data sheet replaces all previous editions. The data on this sheet have been compiled according to the last laboratory report. Technical characteristics can be changed or adapted. We are not responsible for any incomplete information. Before use, one needs to ensure that the product is suitable for his application. Therefore, tests are necessary. Our general conditions apply.

Application (when used as an adhesion primer)

- Apply 1 uniform layer of **Primer PU Turbo** to the subfloor with a roller or a brush. The subfloor must be sufficiently saturated.
- In case of particularly porous and absorbent surfaces, a second coat of **Primer PU Turbo** may be required, with an interval of at least 1 hour (within max. 24 hours).
- When applied correctly, a uniform film forms, improving the adhesion of the parquet adhesive to the surface of the subfloor.
- Avoid mirroring by over-applying the primer. This is detrimental to the adhesion.
- Close the canister tightly after use. Do not return excess product to the canister.

Application (when used as a moisture barrier)

- Two coats of **Primer PU Turbo** should be applied evenly with a roller or a brush, with an interval of at least 1 hour (max. 24 hours).
- For compact and normally absorbent surfaces, one layer of **Primer PU Turbo** is sufficient, provided that the entire surface is evenly covered (untreated parts can prevent the correct operation of the treatment!). If in doubt, it is recommended to apply 2 coats.
- The edges and walls around the subfloor must be coated with 1 layer of **Primer PU Turbo**, to a height of 5 - 6 cm.
- Close the canister tightly after use. Do not return excess product to the canister.

Parquet floor laying

- Bonding of parquet on a subfloor treated with **Primer PU Turbo** should be done within 24 hours.
- Use a 1 component hybrid polymer adhesive **Parabond Parquet** or a 2 component adhesive **Paracol Parquet 2C PU+**.
- If bonding cannot be done within 24 hours, the treated surface should be sprinkled generously with fine sand during the application of the **Primer PU Turbo**. Remove excess sand after the primer has hardened.

Cleaning

- Cured product can only be removed mechanically.

SAFETY

Safety data sheet available online: www.dl-chem.com.

LIMITATIONS

- Do not use the product below 10°C or at a relative humidity below 40%. Curing extends significantly at temperatures below 15°C.
- Not suitable for outdoor use.
- Do not apply in case of standing water.
- Must not, in combination with underfloor heating, be applied as a moisture barrier in case of insufficiently dry screeds.
- Do not use on insufficiently dry anhydrite screed (> 0.5% moisture, measured with carbide meter) to avoid "rotting" of the subfloor.
- Not suitable as a moisture barrier with rising damp. In this case use **Hydroblocker 3K**.
- Not suitable as a moisture barrier on a ceramic tile, marble, varnished surfaces and other non-absorbent surfaces. In this case use **Hydroblocker 3K**.
- Not suitable for direct application of water-based adhesives such as **Paracol Universal Flooring**. In that case apply **Primer PU Turbo**, sand in and apply **DL Egaline** or **DL Maxi Egaline**.

This technical data sheet replaces all previous editions. The data on this sheet have been compiled according to the last laboratory report. Technical characteristics can be changed or adapted. We are not responsible for any incomplete information. Before use, one needs to ensure that the product is suitable for his application. Therefore, tests are necessary. Our general conditions apply.